

GO WHERE OTHERS DON'T DARE: TEENAGERS' BEDROOMS.



TEENAGERS' DESK

The 'A User's guide to Contiboard' leaflet will help you achieve a professional finish. Filled with tips and hints on how to work with Contiboard we recommend this is read before starting your project. All drilling that goes through the board should be started from the visible side.

1



1. Fix one end panel and the base of the small bookcase section together with the appropriate screws. Now fix the other end panel. Assemble the tall bookcase section in the same way.

2



2. Fix the desk top to both the large and small bookcases. The unit will now stand on its own.

3. Fix one tall end panel to the end of the desk top, which already has the small bookcase fitted.

4. Now fix one tall end panel to the end of the desk top, that already has the tall bookcase fitted, join the two tall end panels together with the appropriate screws.

5. Now fix one long shelf to two tall end panels.

6. Position the shelf supports and fit the adjustable shelves.

3



Boards required: 12 x 2000 x 225mm, 1 x 1000 x 600mm, 32 x 50mm chipboard screws, 20 x shelf supports

4



5



6



CUTTING AND DRILLING PLANS

continued...


CUTTING AND DRILLING PLANS

Finished size of teenagers' desk when using supplied plans – Height 1800mm, Width 1300mm, Depth 600mm.
Adapt to suit individual requirements. This unit needs to be made on its back. Some help will be needed to move the finished unit into position. To convert mm to inches divide the metric measurement in millimetres by 25.4.

UNIT 1.


Tall panels x2

Drill 6 holes using a 5mm diameter drill bit through the panel (A).
Drill 20 holes to a depth of 12mm using a 5mm diameter drill bit (B).



Small Ends x2


Drill 4 holes using a 5mm diameter drill bit through the panel (A).
Drill 12 holes to a depth of 12mm using a 5mm diameter drill bit.



Tall Panels x2

Drill 4 holes using a 5mm diameter drill bit through the panel (A).
Drill 8 holes to a depth of 12mm using a 5mm diameter drill bit (B).

Note: the drilling for this panel is offset by 15mm as the shelves sit one on top of the other




UNIT 2.

Long and Short Shelves

Drill 4 holes using a 3mm diameter drill bit to a depth of 20mm.


Long shelves drill x3.

Short shelves drill x1.



Top Panel x1

Drill 12 holes in edges of panel to a depth of 20mm.



THE VERSATILE CONTIBOARD RANGE

A FINISH FOR EVERY SITUATION

Whether you live in a modern or traditional home, storage units can make or break a room. That's why we've designed a range of boards with a high-spec melamine finish that can be made to not only fit the shape of your home, but also the style. And because interior design is constantly changing, we're always developing and broadening our range of different coloured and printed designs. **All you need to do is add imagination.**

TOOLS REQUIRED

- Square, measuring tape and pencil
- Electric power saw with correct blade or hand saw (14 teeth per 25mm)
- Screwdrivers, screws, sharp marking/trimming knife
- Electric iron, glasspaper and block
- Drill with drill bits suitable for wood
 - Drill with 3mm and 5mm drill bits



SIZES AVAILABLE

Finish	White Melamine		Finish effects*
Thickness	15mm	15mm	18mm
Sizes	152 x 1830mm	152 x 2440mm	150 x 2000mm
	229 x 1830mm	229 x 2440mm	250 x 2000mm
	305 x 1830mm	305 x 2440mm	325 x 2000mm
	381 x 1830mm	381 x 2440mm	450 x 2000mm
	533 x 1830mm	533 x 2440mm	600 x 2000mm
	610 x 1830mm	610 x 2440mm	
		762 x 2440mm	
		1220 x 2440mm	

*Finish effects include:

Cherry Modern Effect; Rift Beech Effect; Traditional Oak Effect; Cream Effect; Walnut Effect; Chocolate Oak Effect; Maple Effect and Oak Effect.

The manufacturer reserves the right to withdraw or alter the range or part of the range. Matching ContiStrip iron on edging is available to finish sawn edges.

Caution and Safety

- Care should be taken when working with all timber products and the correct protective equipment used.
- Do not overtighten fixing screws.
- Ensure that you have sufficient working space to construct the unit.
- Heavy units are difficult to move and may require help from an additional person.
- Keep all tools and fixing items out of reach of children to prevent accidents occurring.
- Screw cap covers can easily choke a child. Glue these into place for extra safety.
- Check for wires and pipes with a special battery-powered detector before drilling.
- Always restrain freestanding units if there is a possibility of children climbing on them.
- Cleaning melamine or foil faced particleboard. Use mild soap and water only on a slightly damp cloth. Do not use abrasive or solvent cleaners.

Contiboard has been offering an alternative to ill-fitting, mass-produced, flat-packed furniture for over 25 years. The versatile nature and wide range of appealing finishes of our boards means that during that time they have been made into wardrobes, cupboards, shelving, storage boxes, tables... whatever you could think of really: Some weird, all wonderful.

We look forward to seeing what ideas you come up with in the next 25 years.

Conti
GENUINE PRODUCTS
Norbord

CONTI DIY PRODUCTS
NORBORD LTD
SOUTH MOLTON
DEVON EX36 4HP
TEL. 01769 575400

JUST ADD IMAGINATION