

# CUSTOM MADE CORNER BOOKCASES? WE WROTE THE BOOK.



## CORNER BOOKCASE





The 'A user's guide to Contiboard' leaflet will help you achieve a professional finish. Filled with tips and hints on how to work with Contiboard we recommend this is read before starting your project. All drilling that goes through the board should be started from the visible side.

1. Using the top panel and the shelves without the pre-drilled holes in the face of the panel. Starting with the top panel, and working your way down, fix all the shelves using the appropriate screws. Finish with the last shelf at the bottom.
2. Starting with the top panel, and working your way down, fix the second end panel. Finish with the last shelf at the bottom. You now have a bookcase.
3. To assemble the corner or second unit, lay the completed bookcase on its back and fit the remaining top and shelves at 90° to the shelves of the completed unit then using the pre-drilled holes that you have drilled into the face of the shelves and top panels, fix so the panels overlap as shown in the photograph.
4. When fitting the last end panel ensure that the holes for the bottom shelf measures 7.5mm from the bottom edge of the end panel. Starting with the bottom panel, and working your way up, fix all the remaining shelves through the end panel into the pre-drilled holes in the ends of the shelves and top. Finish with the top panel. Fit screw cover caps to finish. Your unit is now complete.

**Boards required:** 10 x 2000 x 225mm steamed beech veneer, 42 x 50mm chipboard screws, 28 x 25mm chipboard, 42 x beech screw cover caps

## CUTTING AND DRILLING PLANS

Finished size of the corner bookcase when using supplied plans - Height 1800mm, Width 830mm, Depth 225mm. Adapt to suit individual requirements. This unit needs to be made on its back. Some help will be needed to move the finished unit into position. To convert mm to inches divide the metric measurement in millimetres by 25.4.



# THE VERSATILE CONTIBOARD RANGE

## A FINISH FOR EVERY SITUATION

Whether you live in a modern or traditional home, storage units can make or break a room. That's why we've designed a range of boards with a high-spec melamine finish that can be made to not only fit the shape of your home, but also the style. And because interior design is constantly changing, we're always developing and broadening our range of different coloured and printed designs. **All you need to do is add imagination.**

### TOOLS REQUIRED

- Square, measuring tape and pencil
- Electric power saw with correct blade or hand saw (14 teeth per 25mm)
- Screwdrivers, screws, sharp marking/trimming knife
- Electric iron, glasspaper and block
- Drill with drill bits suitable for wood
  - Drill with 3mm and 5mm drill bits



### SIZES AVAILABLE

Finish	White Melamine		Finish effects*
Thickness	15mm	15mm	18mm
<b>Sizes</b>	152 x 1830mm	152 x 2440mm	150 x 2000mm
	229 x 1830mm	229 x 2440mm	250 x 2000mm
	305 x 1830mm	305 x 2440mm	325 x 2000mm
	381 x 1830mm	381 x 2440mm	450 x 2000mm
	533 x 1830mm	533 x 2440mm	600 x 2000mm
	610 x 1830mm	610 x 2440mm	
		762 x 2440mm	
		1220 x 2440mm	

#### \*Finish effects include:

Cherry Modern Effect; Rift Beech Effect; Traditional Oak Effect; Cream Effect; Walnut Effect; Chocolate Oak Effect; Maple Effect and Oak Effect.

The manufacturer reserves the right to withdraw or alter the range or part of the range. Matching ContiStrip iron on edging is available to finish sawn edges.

#### Caution and Safety

- Care should be taken when working with all timber products and the correct protective equipment used.
- Do not overtighten fixing screws.
- Ensure that you have sufficient working space to construct the unit.
- Heavy units are difficult to move and may require help from an additional person.
- Keep all tools and fixing items out of reach of children to prevent accidents occurring.
- Screw cap covers can easily choke a child. Glue these into place for extra safety.
- Check for wires and pipes with a special battery-powered detector before drilling.
- Always restrain freestanding units if there is a possibility of children climbing on them.
- Cleaning melamine or foil faced particleboard. Use mild soap and water only on a slightly damp cloth. Do not use abrasive or solvent cleaners.

Contiboard has been offering an alternative to ill-fitting, mass-produced, flat-packed furniture for over 25 years. The versatile nature and wide range of appealing finishes of our boards means that during that time they have been made into wardrobes, cupboards, shelving, storage boxes, tables... whatever you could think of really: Some weird, all wonderful.

**We look forward to seeing what ideas you come up with in the next 25 years.**

**Conti**  
GENUINE PRODUCTS  
Norbord

CONTI DIY PRODUCTS  
NORBORD LTD  
SOUTH MOLTON  
DEVON EX36 4HP  
TEL. 01769 575400

**JUST ADD IMAGINATION**