



# A WARDROBE SHOULD FIT A ROOM LIKE A TAILORED SUIT.



## WARDROBE

The 'A user's guide to Contiboard' leaflet will help you achieve a professional finish. Filled with tips and hints on how to work with Contiboard we recommend this is read before starting your project. All drilling that goes through the board should be started from the visible side.



1. Fix one end panel and the top together with the appropriate screws. Now fix the base panel to the end panel (when fixing the base panel to the end panels a gap of 10mm needs to be left - see drawing A). Finally, fix the second end panel to the top and base.
2. Next assemble the middle section by taking one of the middle unit side panels and starting at the top fit all the middle section shelves. Then fit the other middle unit side panel using appropriate screws.
3. Middle section completed.
4. Fit the completed middle section into the main unit using your pre-drilled holes and the appropriate screws.
5. Fit the two wide shelves one on each side of the main unit using pre-drilled holes.
6. Position and fit the blind and bottom rails using pre-drilled holes.  
If creating unit with shelves to the right hand side now position the remaining 3 wide shelves and dividers.

### Finishing touches

7. Buy blinds, trim to size and fit behind the blind rail.
8. Finally, cut to size and fit hanging rails.


**Wardrobe illustrated features hanging space on both sides - version B shows plans for multi-storage space below.**

**Boards required:** 6 x 2000 x 450mm, 1 x 1000 x 525mm, 20 x 50mm chipboard screws, 8 x 25mm chipboard screws, piano hinge and appropriate screws



To work out the drill positions for the additional shelves in Version B, position one of the dividers against the inner end panel on top of the base panel. Draw a line along the divider's top edge. Measure 9mm up and mark. From front and back edges of end panel measure and mark 100mm. Using a 5mm drill bit drill to create shelf fixing hole - use a piece of spare board as a buffer on outer face to prevent the surface chipping. Use this fixed shelf as the base to find the other shelf positions by repeating these steps as you work up the unit. Position the shelf dividers to suit and glue in place as desired.

### Version (B)



## CUTTING AND DRILLING PLANS


continued...

# CUTTING AND DRILLING PLANS

Finished size of wardrobe when using supplied plans – Height 1800mm, Width 1580mm, Depth 600mm. Adapt to suit individual requirements. This unit needs to be made on its back. Some help will be needed to move the finished unit into position. To convert mm to inches divide the metric measurement in millimetres by 25.4.


## End Panels x2

Drill 6 holes using a 5mm diameter drill bit through the panel.




## Middle Section Shelves (x4)

Drill 4 holes using a 3mm diameter drill bit to a depth of 20mm to each end of the panel.




## Mid Unit Side Panels x2

Drill 4 holes using a 3mm diameter drill bit to a depth of 20mm (A) to each end of the panel. Drill 10 holes using a 5mm diameter drill bit through the panel (B).




## Wide Shelf x2 (On version 'B' x3 additional shelves will be required)

Drill both shelves. Drill 4 holes using a 3mm diameter drill bit to a depth of 20mm to each end of the panel.




## Top and Base x2

Drill 4 holes using a 3mm diameter drill bit to a depth of 20mm (A) to each end of the panel. Drill 4 holes using a 5mm diameter drill bit through the panel (B).




## Blind and bottom rails x2

Drill 10 holes using a 5mm diameter drill bit through the panel. Drilling for the blinds will depend on the type purchased.



## Dividers x6 Only required if making version 'B' (No drilling)



# THE VERSATILE CONTIBOARD RANGE

## A FINISH FOR EVERY SITUATION

Whether you live in a modern or traditional home, storage units can make or break a room. That's why we've designed a range of boards with a high-spec melamine finish that can be made to not only fit the shape of your home, but also the style. And because interior design is constantly changing, we're always developing and broadening our range of different coloured and printed designs. **All you need to do is add imagination.**

### TOOLS REQUIRED

- Square, measuring tape and pencil
- Electric power saw with correct blade or hand saw (14 teeth per 25mm)
- Screwdrivers, screws, sharp marking/trimming knife
- Electric iron, glasspaper and block
- Drill with drill bits suitable for wood  
– Drill with 3mm and 5mm drill bits



### SIZES AVAILABLE

Finish	White Melamine		Finish effects*
	15mm	15mm	
<b>Thickness</b>			<b>18mm</b>
<b>Sizes</b>	152 x 1830mm 229 x 1830mm 305 x 1830mm 381 x 1830mm 533 x 1830mm 610 x 1830mm	152 x 2440mm 229 x 2440mm 305 x 2440mm 381 x 2440mm 533 x 2440mm 610 x 2440mm 762 x 2440mm 1220 x 2440mm	150 x 2000mm 250 x 2000mm 325 x 2000mm 450 x 2000mm 600 x 2000mm

#### \*Finish effects include:

Cherry Modern Effect; Rift Beech Effect; Traditional Oak Effect; Cream Effect; Walnut Effect; Chocolate Oak Effect; Maple Effect and Oak Effect.

The manufacturer reserves the right to withdraw or alter the range or part of the range. Matching ContiStrip iron on edging is available to finish sawn edges.

#### Caution and Safety

- Care should be taken when working with all timber products and the correct protective equipment used.
- Do not overtighten fixing screws.
- Ensure that you have sufficient working space to construct the unit.
- Heavy units are difficult to move and may require help from an additional person.
- Keep all tools and fixing items out of reach of children to prevent accidents occurring.
- Screw cap covers can easily choke a child. Glue these into place for extra safety.
- Check for wires and pipes with a special battery-powered detector before drilling.
- Always restrain freestanding units if there is a possibility of children climbing on them.
- Cleaning melamine or foil faced particleboard. Use mild soap and water only on a slightly damp cloth. Do not use abrasive or solvent cleaners.

Contiboard has been offering an alternative to ill-fitting, mass-produced, flat-packed furniture for over 25 years. The versatile nature and wide range of appealing finishes of our boards means that during that time they have been made into wardrobes, cupboards, shelving, storage boxes, tables... whatever you could think of really: Some weird, all wonderful.

**We look forward to seeing what ideas you come up with in the next 25 years.**



**JUST ADD IMAGINATION**

**CONTI DIY PRODUCTS  
NORBORD LTD  
SOUTH MOLTON  
DEVON EX36 4HP  
TEL. 01769 575400**